




cod.1163XXXX GB
rev.01 (software VER. 1.35)
2006-06-28



PROGRAMMING INSTRUCTIONS PARAMETERS

“USER” Menu,
“ASSISTANCE” Menu,
“MANUFACTURER” Menu

RAIN STAR 260




STARTEC s.r.l. 33078 SAN VITO AL TAGLIAMENTO (PN) Italy – via Buia, 7
tel. ++39 0434 85001 Internet :Web <http://www.startecitaly.com/>
fax ++39 0434 85002 e-mail: sales@startecitaly.com

TABLE OF CONTENTS:

TABLE OF CONTENTS:	1
1. GENERAL	2
1.1 Dual functionality of the keys – Use	2
2. USER MENU	3
Accessing the “USER” Menu	3
List of messages in the USER menu	3
Changing the language	3
Adjusting the contrast	3
Adjusting the brightness	3
Saving the changes	4
Cancelling changes	4
3. ASSISTANCE MENU	5
Accessing the “ASSISTANCE” Menu	5
Saving changes	6
Cancelling changes	6
4. MANUFACTURER MENU	7
Accessing the “MANUFACTURER” Menu	7
4.1 Selecting and loading a model	7
Saving changes	8
Cancelling changes	8
4.2 Parameters menu	8
Saving changes	9
Cancelling changes	9
Details of the Manufacturer Menu	9
Saving changes	15
Cancelling changes	15

1. GENERAL




in this manual it is referred to by using the symbol **m**



in this manual it is referred to by using the symbol **h**

1.1 Dual functionality of the keys – Use.

Keys in the **+** and **-** group have a dual function which becomes active when you access a menu.. As you may notice, these keys have a symbol depicted at lower right. This symbol indicates their dual functionality.



TASTO	FUNZIONE
ESCAPE ESC	cancel operation
ENTER ENTER	when pressed once, lets you modify the parameter You can tell when the parameter can be modified, because the * (asterisk) appears on the display - When ENTER is pressed a second time, the change is confirmed and the asterisk disappears.
FRECCIA SU ^	modifies upwards by one unit
FRECCIA DESTRA >	modifies upwards by one tenth
FRECCIA GIU v	modifies downwards by one unit
FRECCIA SINISTRA <	modifies downwards by one tenth

Note: keeping the ARROW key pressed raises the speed of increase or decrease.

During navigation through the menus, when the display shows a full row of dots along the bottom, e.g. [B.R.I.G.H. .8.O.] it indicates that the end has been reached in that direction, or that modification is not allowed.

2. USER MENU

Accessing the “USER” Menu

To access the USER menu, go through the following stages:

Note: some messages may not appear because the functions are not enabled, and some messages which are not described may appear, if enabled.

Stage	action	display	notes
1	Switch off the control unit	[]	
2	Switch on the control unit, keeping the m key pressed until the message "OK MENU" appears on the display s(after several seconds).	[STARTEC] [R.S.260] [VER 1.18] [- - - -] [OK MENU]	- Manufacturer's name - Model of machine - Program version - User menu - Access enabled

List of messages in the USER menu

When the DOWN ARROW **v** is pressed several times, the following messages are displayed in turn:

POS	DISPLAY	MEANING
1	[LANG ENG]	- Displays the language used for messages
2	[CONTR 90]	- Adjustment for contrast of the display
3	[BRIGH 80]	Adjustment for brightness of the display back-lighting

When the UP ARROW **^** is pressed several times, the same messages are displayed in reverse order.

Changing the language

In this menu it is not possible to change the language.

Adjusting the contrast

Per modificare il contrasto seguire le seguenti fasi:

STAGE	ACTION	DISPLAY	NOTE
1	Press the arrow keys v and ^ till the display shows	[CONTR 90]	
2	Press the ENTER key	[CONTR*90]	The asterisk appears, changes are enabled
3	Press ^ or > to increase the value by a unit or a tenth respectively at a time Press v or < to reduce the value, by a unit or a tenth respectively at a time.	[CONTR*92] [CONTR*79]	Higher value means more contrast Maximum value 99. Minimum value 0
4	Press ENTER to confirm the value for contrast	[CONTR 79]	
5	Press v or ^ to carry on moving through the menu for making any other changes. Press the START key to save the changes you have made, or press the ESC key to cancel all the changes (see § Saving changes or Cancelling changes). This stage takes you out of the menu.		

Adjusting the brightness

To modify the brightness, go through the following stages:

STAGE	ACTION	DISPLAY	NOTE
1	Press the arrow keys v and ^ till the display shows	[BRIGH 80]	
2	Press the ENTER key	[BRIGH*80]	The asterisk appears, changes are enabled

3	Press ^ or > to increase the value by a unit or a tenth respectively at a time - Press v or < to reduce the value by a unit or a tenth respectively at a time	[<i>BRIGH*92</i>] [<i>BRIGH*79</i>]	Higher value means more brightness. Maximum value 99 Minimum value 0
4	Press ENTER to confirm the value for brightness.	[<i>BRIGH 79</i>]	- The asterisk disappears.
5	Press v or ^ to carry on moving through the menu for making any other changes. Press the START key to save the changes you have made, or press the ESC key to cancel all the changes (see § Saving changes or Cancelling changes). This stage takes you out of the menu.		

Saving the changes

To save the changes which you have made to the Rain Star 260's memory:

STAGE	ACTION	DISPLAY	NOTE
1	Press the START START key. Press the START START key again	[<i>CHN SAVE</i>] [<i>SAVES CH</i>]	Requests SAVE CHaNges SAVES the CHanges

Once this operation is completed, the Rain Star 260 exits from the Menu and goes to the stage of

Cancelling changes

To cancel the changes which you have made:

STAGE	ACTION	DISPLAY	NOTE
1	Press the ESCAPE ESC key. Press the ESCAPE ESC key again	[<i>CANC CHN</i>] [<i>CH N SAV</i>]	- requests CANCEL CHaNges - the CHanges are Not SAVed.

Once this operation is completed, the Rain Star 260 exits from the Menu and starts to work

The Rain Star 260 uses the metric system.

3. ASSISTANCE MENU

Accessing the “ASSISTANCE” Menu

To access the ASSISTANCE Menu, follow the same procedure as for the MANUFACTURER Menu, keying "111" or other preset password.

This gives access to the entire User menu and some functions which have been enabled on the Manufacturer menu.

Access the ASSISTANCE menu as follows:

Note: some options will not be displayed if they are not enabled.

FASE	ACTION	DISPLAY	NOTE
1	Switch off the control unit	[]	
2	Switch on the control unit, keeping the m and h keys pressed until the Display prompts for a password	[STARTEC] [R . S . 260] [VER 1.18] [- - - - -] [PWD - -]	- Manufacturer's name - Model of machine - Program version - If the password is not entered within 5 seconds by pressing a +/- key, the machine goes into working mode
3	Press the Initial Pause + or - keys to display the 1st digit.	[PWD 1--]	e.g. password = 111
4	Press the Speed + or - keys to display the 2nd digit.	[PWD -1-]	e.g. password = 111
5	Press the Final Pause + or - keys to display the 3rd digit.	[PWD --1]	e.g. password = 111
6	Press the START key	[MN ASSIS]	- Menu Assistance
7	Displayed a few seconds after releasing the START button	[OK MENU]	- access to the menu enabled
8	Displayed in the event of password error	[ERR PWD]	- Password error. Repeat procedure for stage 1
9	Pressing the v key appears	[VLV OUTL]	Position of the valve for stopping work
10	Press the v cursor key again to scroll through the following menu options		
	<i>DISPLAY</i>	<i>DESCRIPTION</i>	
	[VLV YES] o [VLV NO]	Valve for starting/stopping work: ACTIVE or INACTIVE.	
	[WI 0:00]	Waiting start Irrigation. The waiting time, in hours and minutes, can be set by using the second function of the H key.	
	[SECTORS]	If it is enabled, it permits the management of irrigation up to 8 different speeds (sector irrigation). With more than 0 sectors, it is possible to set the maximum running time of irrigation.	
	[NoSTP mO] o [STOP mO]	No Stop at metres = 0. Rewinding continues until the signal from the End Rewind sensor (the display may show negative metres). Or, STOP at metres = 0. Rewinding stops when the machine indicates m. of pipe = 0.	
	[OUTPUTS]	Management of output sources: OU1, OU2 and OU3 (the last one appears on RAIN V.03 boards and following models).	
	[INPUTS]	Management of input sources: IA1, IA2, IA3 and 4-20mA. Reminder: the inlets IA1, IA2, IA3 are activated when they are switched to ground through a signal or a contact.	
	[UM METRI] or [UM FEET]	Units of Measurement: decimal METRIC system.or, Imperial (US) measuring system.	
	[LANG ITA] , [LANG FRA] , [LANG ENG] or [LANG GER]	Language used for display.	

	[<i>SWOF 0'</i>]	Setting of minutes for the auto-SWitchOff of the machine after the end of irrigation.
	[<i>GSM ON</i>] or [<i>GSM OFF</i>]	Enables and disables the GSM function, if present
	[<i>CONTR 90</i>]	Adjustment for CONTRast of the display.
	[<i>BRIGH 80</i>]	Adjustment for BRIGHtness of the display back-lighting.
11	Pressing the up arrow 	again displays the last messages in reverse order.

Saving changes

Save changes in the Rain Star 260 memory as follows:

- see “saving changes” at the end of chapter 2

Once complete, the unit reboots and displays the message [*RE-START*].

Cancelling changes

To cancel one or more changes, proceed as follows:

- see “cancelling changes” at the end of chapter 2

Once complete, the unit reboots and displays the message [*RE-START*].

4. MANUFACTURER MENU

Accessing the “MANUFACTURER” Menu

To access the MANUFACTURER Menu, follow the procedure described in the following stages:

Note: some messages may not appear because the functions are not enabled.

STAGE	ACTION	DISPLAY	NOTE
1	Switch off the control unit	[]	
2	Switch on the control unit, keeping the m and h keys pressed until the Display shows the message "MENU"(after several seconds) and prompts for a password	[STARTEC] [R.S.260] [VER 1.18] [PWD ---]	- Manufacturer's name - Model of machine - Program version - If the password is not entered within 5 seconds by pressing a +/- key, the machine goes into working mode
3	Press the Initial Pause + or - keys to display the 1st digit.	[PWD 2--]	e.g. password = 222
4	Press the Speed + or - keys to display the 2nd digit.	[PWD -2-]	e.g. password = 222
5	Press the Final Pause + or - keys to display the 3rd digit.	[PWD --2]	e.g. password = 222
6	Press the START key	[MN MANUF]	- MeNu MANUFACTURER
7	Displayed a few seconds after releasing the START button	[OK MENU]	- access to the menu enabled
8	Displayed in the event of password error	[ERR PWD]	- Password error. Repeat procedure for stage 1

4.1 Selecting and loading a model

9	Press the > cursor key, the following is displayed	[CMOD 17]	- e.g. model code in position 17
10	Press the v cursor key, the following is displayed	[STARTEC]	- e.g. constructor name
11	Press the ^ cursor key to return to the previous screen	[CMOD 17]	- e.g. model code in position 17
12	Press ENTER	[CMOD* 17]	- The asterisk is displayed, enabling changes
13	Press h . The model corresponding to position 17 is displayed	[S400X125]	- e.g. STARTEC model with 400 m length, 125 mm diameter tube
14	- Press the ^ or v cursor keys to scroll through the entire list of your models and default STARTEC models - Press the > or < cursor keys to skip 10 positions	[S500X100]	- irrigator model
15	Displayed if no keys are pressed	[CMOD* 17]	- Model position
16	Press ENTER to load the parameters for the selected model	[R MO OK]	- Parameters successfully loaded
17	Press the < cursor key to check if the data for the selected model has been loaded. Use the cursor keys to scroll through the menu options	[VLV SCAR]	- the first menu option is displayed
18	If all changes are correct, Save changes , otherwise Cancel changes .		

Saving changes

Save changes in the Rain Star 260 memory as follows:

- see “saving changes” at the end of chapter 2

Once complete, the unit reboots and displays the message [**RE-START**].

Cancelling changes

To cancel one or more changes, proceed as follows:

- see “cancelling changes” at the end of chapter 2

Once complete, the unit reboots and displays the message [**RE-START**].

4.2 Parameters menu

Restarting by the 8 stage of the “accessing the manufacturer menu”

9	Pressing the v key appears	[VLV OUTL]	Position of the valve for stopping work
10	Press the v cursor key again to scroll through the following menu options		
	DISPLAY	DESCRIPTION	
	[VLV YES] o [VLV NO]	Valve for starting/stopping work: ACTIVE or INACTIVE.	
	[WI 0:00]	Waiting start Irrigation. The waiting time, in hours and minutes, can be set by using the second function of the H key.	
	settori	If it is enabled, it permits the management of irrigation up to 8 different speeds (sector irrigation). With more than 0 sectors, it is possible to set the maximum running time of irrigation.	
	[NoSTP mO] o [STOP mO]	No Stop at metres = 0. Rewinding continues until the signal from the End Rewind sensor (the display may show negative metres). Or, STOP at metres = 0. Rewinding stops when the machine indicates m. of pipe = 0.	
	[ALRM mhO] or [NoAL mhO]	ALaRM in the case of lack of speed during rewinding (m/h = 0). The alarm consists in the stopping of irrigation. or, "No ALarm at m/h = 0". In this case, in the event of zero speed, irrigation is not stopped but the machine remains on standby, indicating [m/h ZERO].	
	[OUTPUTS]	Management of output sources: OU1, OU2 and OU3 (the last one appears on RAIN V.03 boards and following models).	
	[INPUTS]	Management of input sources: IA1, IA2, IA3 and 4-20mA. Reminder: the inlets IA1, IA2, IA3 are activated when they are switched to ground through a signal or a contact.	
	[MOT FLOW]	Programming of sensitivity of activation of the flow valve motor in relation to the load (type of valve), and programming of the maximum time of activation of the motor itself.	
	[MOT REG]	Programming of sensitivity of activation of the regulating motor in relation to the load, and of the operational settings for regulation (duration of the regulating pulses), and programming of the maximum time of activation of the motor itself.	
	[SENSORS]	By pressing > a submenu appears with the following items: SPEed SENSO applied to the irrigator: ROLLER or PINion with relative settings and tables. PREssure sensor and its enabling (always enabled). Sensor of ReWinding End, its enabling (always enabled) and the opportunity to delay the cycle of irrigation end to let the loading of the gun cart on the irrigator.	
	[UM METRI] or [UM FEET]	Units of Measurement: decimal METRIC system.or, Imperial (US) measuring system.	
	[LANG ITA] , [LANG FRA] , [LANG ENG] or [LANG GER]	Language used for display.	

[PWD ASST]	Setting a new ASSisTance PassWorD (to be implemented)
[SYSTEM]	Access to a sub-menu for setting several functions relating to the keypad and display, e.g. display of decimals.
[SWOF 0']	Setting of minutes for the auto-SWitchOff of the machine after the end of irrigation.
[GSM ON] [GSM OFF]	Enables and disables the GSM function, if present
[CONTR 90]	Adjustment for CONTRast of the display.
[BRIGH 80]	Adjustment for BRIGHtness of the display back-lighting.
11	Pressing the up arrow  again displays the last messages in reverse order.

Saving changes

Save changes in the Rain Star 260 memory as follows:

- see “saving changes” at the end of chapter 2

Once complete, the unit reboots and displays the message [RE-START] .

Cancelling changes

To cancel one or more changes, proceed as follows:

- see “cancelling changes” at the end of chapter 2

Once complete, the unit reboots and displays the message [RE-START]

Details of the Manufacturer Menu

For navigating and for selecting the various options, use the keys as described in the paragraph “Dual functionality of the keys – Use”.

[VLV YES] o	Valve for starting/stopping work: ACTIVE or INACTIVE.
[VLV NO]	Pressing  takes you to a sub-menu with the following options:
[[VLV OUTL] o	Position of the valve for starting/stopping work: in OUTLET or INTAKE position.
[VLV INTK]	Pressing  takes you to a sub-menu with the following options:
[ENMA VLV] o	=>ENables Modification by the Assistance
[ENRU VLV] o	=> ENables Read-only by the User
[ENMU VLV]	=> ENables Modification by the User
	These options enable or disable the selection of the valve position by the Assistance and the User.
[V I CLOS] [V I OPEN]	These options let you choose whether the Valve on the Intake should be OPEN or CLOSED at the start of irrigation.
[V OUTLET]	Pressing  takes you to a sub-menu with the following options:
[VOO 120 "]	This parameter lets you set the time for which the Valve mounted on the Outlet should remain Open at the end of irrigation before reclosing (maximum programmable time is 250 seconds). Programming 0 makes the valve remain open.
[V INTAKE]	Pressing  takes you to a sub-menu with the following options:
[VIC 7 "]	This parameter lets you set the time for continuous activation of the Valve mounted on the Intake, before pulse activation begins, during the CLOSURE phase (maximum programmable time is 250 seconds)
[VIPN 0.50]	This parameter lets you set the duration of the PULSE to the Valve mounted on the Intake, during Pulse activation (time oN), during the CLOSURE phase (maximum programmable time is 2.50 seconds).
[VIPF 2.50]	This parameter lets you set the duration of the interval between one pulse to the Valve mounted on the Intake and the next, during Pulse activation (time off), during the CLOSURE phase (maximum programmable time is 2.50 seconds)

[DPO 0"]	this parameter for the inlet valve sets the delay time for the pressure test at the start of the irrigation cycle in order to fill the tube (maximum time settable 999 seconds)
----------	---

[WI 0:00]	Waiting start Irrigation. The waiting time, in hours and minutes, can be set by using the second function of the H key. Maximum waiting time settable is 99 hours 59 minutes. The waiting time can be modified and activated before each Start Irrigation. If set to 0, the parameter does not appear; if a value other than 0 is set, the programmed value is offered as default. Pressing  takes you to a sub-menu with the following options:
-----------	--

[ENMA WTI]	=>ENables Modification by the Assistance
[ENRU WTI]	=>ENables Read-only by the User
[ENMU WTI]	=>ENables Modification by the User
These options enable or disable the choice of Waiting Time before Irrigation, by the assistance or the user.	

[SECTORS]	If it is enabled, it permits the management of irrigation up to 8 different speeds (sector irrigation). With more than 0 sectors, it is possible to set the maximum running time of irrigation. Press  key to access a sub menu with the following SECTORS options
-----------	--

[NumSECT 0]	This entry establishes the number of sectors that require irrigation. Number of programmable sectors: 0 = with no supplementary features 1 = with Maximum Running Time and Initial Holding Time 2-8= with SECTORS, Maximum Running Time and Initial Holding Time Press  to access length and speed parameters of the various sectors. (the data in this table are all modifiable and can be scrolled either up or down):
-------------	--

[m 1 100.0]	This entry specifies the length of sector 1. Press  to display another entry
-------------	---

[m/h1 25.0]	This entry specifies the speed of sector 1, m/h.
-------------	--

[m 2 100.0]	This entry specifies the length of sector 2. Press  to display another entry.
-------------	--

[m/h2 25.0]	This entry specifies the speed of sector 2, m/h.
-------------	--

[m x 100.0]	This entry specifies the length of sector x. Press  to display another entry
-------------	---

[m/hx 25.0]	This entry specifies the speed of sector x, m/h.
-------------	--

[m 8 100.0]	This entry specifies the length of sector 8. Press  to display another entry.
-------------	--

[m/h8 25.0]	This entry specifies the speed of sector 8, m/h.
-------------	--

[ENMC SET]	=>Enable Modification by the Manufacturer
[ENRA SET]	=>ENables Read by the Assistance
[ENMA SET]	=>ENables Modification by the Assistance
[ENRU SET]	=>ENables Read-only by the User.
[ENMU SET]	=>ENables Modification by the User

[NoSTP mO] o [STOP mO]	No Stop at metres = 0. Rewinding continues until the signal from the End Rewind sensor. Or, STOP at metres = 0. Rewinding stops when the machine indicates metres of hose = 0 (ZERO). Pressing  takes you to a sub-menu with the following options:
---------------------------	--

[ENRA SmO] o	=>ENables Read by the Assistance
[ENMA SmO] o	=>ENables Modification by the Assistance
[ENRU SmO]	=> ENables Read-only by the User
[ENMU SmO]	=> ENables Modification by the User
These options enable or disable the selection of the valve position by the Assistance and the User	

<p>[ALRM mho] o [NoAL mho]</p>	<p>ALarM in the case of lack of speed during rewinding (m/h = 0). The alarm consists in the stopping of irrigation. Or, "No Alarm at m/h = 0". In this case, in the event of zero speed, irrigation is not stopped but the machine remains on standby, indicating [m/h ZERO]. Pressing  takes you to a sub-menu with the following options:</p>
	<p>[DSRA mho] =>DiSables Reading by the Assistance (the option does not appear on the Assistance menu) [ENRA mho] =>ENables Read by the Assistance [ENMA mho] =>ENables Modification by the Assistance [ENRU mho] =>ENables Read-only by the User. [ENMU mho] =>ENables Modification by the User</p>

<p>[OUTPUTS]</p>	<p>Management of output sources: OU1, OU2 and OU3 (the last one appears on RAIN V.03 boards and following models). Pressing  takes you to a sub-menu with the following options:</p>
	<p>[OU1 DIS] => Auxiliary outlet 1 => DISabled [OU1 ENAB] => Auxiliary outlet 1 => ENabled. Pressing  takes you to a sub-menu with the following options:</p>
	<p>[ENMA OU1] => ENables Modification by the Assistance [ENRA mhO] =>ENables Read by the Assistance [ENRU OU1] => ENables Read by the User [ENMU OU1] =>ENables Modification by the User Pressing  takes you to a sub-menu with the following options:</p>
	<p>[OU1 O'] Programming of time of activation (up to 250 minutes) of outlet OU1 for managing an Auxiliary Valve (maximum load 300 mA). Offers two options for counting time: from the start of irrigation, or before the end. Pressing  takes you to a sub-menu with the following options</p>
	<p>[OU1 END] activate Auxiliary Valve 1 from the START, or before the END, of irrigation. [OU1 BIG]</p>
	<p>[OU2 DIS] => Auxiliary outlet 2 => DISabled [OU2 ENAB] => Auxiliary outlet 2 => ENabled. Reminder: this outlet is not implemented by now. Pressing  takes you to a sub-menu with the following options:</p>
	<p>[ENMA OU2] =>ENables Modification by the Assistance [ENRU OU2] =>ENables Read-only by the User. [ENMU OU2] =>ENables Modification by the User</p>
	<p>[OU3 DIS] => Auxiliary outlet 3 => DISabled [OU3 ENAB] => Auxiliary outlet 3 => ENabled. Reminder: this outlet is not implemented by now. Pressing  takes you to a sub-menu with the following options:</p>
	<p>[ENMA OU3] =>ENables Modification by the Assistance [ENRU OU3] =>ENables Read-only by the User. [ENMU OU3] =>ENables Modification by the User</p>

<p>[INPUTS]</p>	<p>Management of input sources: IN1, IN2, IN3 and 4-20mA. Reminder: the inlets IN1, IN2, IN3 are activated when they are switched to ground through a signal or a contact. Pressing  takes you to a sub-menu with the following options:</p>
	<p>[IN1 WIND] => This function has to be implemented [IN1 STOP] =>Auxiliary inlet 1 => Enabled to receive a signal from the outside to give a command STOP irrigation (to be implemented). [IN1 SUSP] => Auxiliary inlet 1 => Enabled to receive a signal from the outside to give a command PAUSE irrigation (to be implemented). [IN1 STAR] => Auxiliary inlet 1 => Enabled to receive a signal from the outside to give a command START irrigation. [IN1 DIS] => Auxiliary outlet 1 => DISabled Pressing  takes you to a sub-menu with the following options:</p>
	<p>[ENMA IN1] =>ENables Modification by the Assistance [ENRU IN1] =>ENables Read-only by the User. [ENMU IN1] =>ENables Modification by the User</p>

[IN2 WIND]	=> This function has to be implemented	
[IN2 STOP]	=> Auxiliary inlet 2 => Enabled to receive a signal from the outside to give a command STOP irrigation (to be implemented).	
[IN2 SUSP]	=> Auxiliary inlet 2 => Enabled to receive a signal from the outside to give a command PAUSE irrigation (to be implemented).	
[IN2 STAR]	=> Auxiliary inlet 2 => Enabled to receive a signal from the outside to give a command START irrigation.	
[IN2 DIS]	=> Auxiliary outlet 2 => DISabled Pressing  takes you to a sub-menu with the following options:	
	[ENMA IN2]	=>ENables Modification by the Assistance
	[ENRU IN2]	=>ENables Read-only by the User.
	[ENMU IN2]	=>ENables Modification by the User
[IN3 WIND]	=> This function has to be implemented	
[IN3 STOP]	=> Auxiliary inlet 3 => Enabled to receive a signal from the outside to give a command STOP irrigation (to be implemented). => Auxiliary outlet 3 => DISabled	
[IN3 SUSP]	=> Auxiliary inlet 3 => Enabled to receive a signal from the outside to give a command PAUSE irrigation (to be implemented).	
[IN3 STAR]	=> Auxiliary inlet 3 => Enabled to receive a signal from the outside to give a command START irrigation.	
[IN3 DIS]	=> Auxiliary outlet 3 => DISabled Pressing  takes you to a sub-menu with the following options:	
	[ENMA IN3]	=>ENables Modification by the Assistance
	[ENRU IN3]	=>ENables Read-only by the User.
	[ENMU IN3]	=>ENables Modification by the User
[420 DIS]	=> Inlet 4-20 mA => DISabled	
[420 ENAB]	=> Inlet 4-20 mA => ENabled. (to be implemented). Pressing  takes you to a sub-menu with the following options suivants:	
	[ENMA 420]	=>ENables Modification by the Assistance
	[ENRU 420]	=>ENables Read-only by the User.
	[ENMU 420]	=>ENables Modification by the User Pressing  takes you to a sub-menu with the following options:

[MOT FLOW]	Pressing  takes you to a sub-menu with the following options relating to the MOTor which operates the FLOW valve: (WARNING: alter these parameters only if you are very familiar with the characteristics of reduction motors and valves.)	
	[FOI 4.OA]	upper limit of current which the Flow valve motor can tolerate in the Opening phase (I max = 5 Ampere).
	[FCI 3.OA]	Upper limit of current which the Flow valve motor can tolerate in the Closing phase (I max = 5 Ampere).
	[TLF 150"]	Time Limit for activation which the Flow valve is allowed for reaching full opening or closing. If the time limit is exceeded without the action being completed, the command to the motor is cancelled and irrigation continues. The maximum programmable time is 250 seconds.

[MOT REG]	Pressing  takes you to a sub-menu with the following options relating to the MOTor which performs the REGulation of the takeup speed. (WARNING: alter these parameters only if you are very familiar with the characteristics of reduction motors, valves and the irrigator.)	
	[RMI 4.OA]	Upper limit of current which the Regulating Motor can tolerate(I max = 5 Ampere).
	[TLR 40"]	Time Limit allowed for carrying out complete Regulation. If the time limit is exceeded without the action being completed, the command to the motor is cancelled and irrigation continues. The maximum programmable time is 250 seconds.

[SENSORS]	By pressing  a submenu appears with the following items: SPEed SENSor applied to the irrigator: ROLLER or PINion with relative settings and tables. PreSsure sensor and its enabling (always enabled). Sensor of ReWinding End, its enabling (always enabled) and the opportunity to delay the cycle of irrigation end to let the loading of the gun cart on the irrigator.	
------------	---	--

[SPD SENS]	Pressing > takes you to a sub-menu with the following options relating to the SPEED SENSOR attached to the irrigator: ROLLER or PINION.	
[SS ROLLE]	Pressing > takes you to a sub-menu with the following option:	
[SS PINI]	[SSR 100.0]	this parameter lets you input the diameter of the Roller. This dimension is expressed in millimetres with increments of 1/10 mm.
[TAB LAYE]	TABLE of LAYERs (applies only to the sensor mounted on the pinion). Pressing > takes you to the Table of Layers with the following options (the data in this table are all modifiable and can be scrolled upwards or downwards):	
	[LL1 448.4]	this figure indicates at what Length Layer 1 finishes. Pressing > takes you to another datum figure.
	[PL1 16.0]	indicates the Parameter of Layer 1, mm/imp.
	[LL2 388.5]	this figure indicates at what Length Layer 2 finishes. Pressing > takes you to another datum figure.
	[PL2 19.0]	indicates the Parameter of Layer 2, mm/imp
	[LLX 320.3]	this figure indicates at what Length Layer X finishes. Pressing > takes you to another datum figure.
	[PLX 22.0]	indicates the Parameter of Layer X, mm/imp
	[LL9 0.0]	this figure indicates at what Length Layer 9 finishes. Pressing > takes you to another datum figure.
	[PL9 36.0]	indicates the Parameter of Layer 9, mm/imp
[AUTO CAL]	AUTOMATIC CALCULATION of the table of layers (applies only to the sensor mounted on the pinion). Pressing > takes you to the parameters for the construction data of the irrigator. By suitably filling in the items listed below, you can get the table of layers filled in automatically:	
	[LPI 500.0]	this figure indicates the Length of the Pipe. Expressed in metres. Maximum length 1000 m
	[DPIP 140]	this figure indicates the Diameter of the PIPE. Expressed in millimetres. Maximum diameter 200 mm
	[DRE 1540]	this figure indicates the Diameter of the REel. Expressed in millimetres. Maximum diameter 2000 mm.
	[WRE 1536]	this figure indicates the Width of the REel. Expressed in millimetres. Maximum width 2000 mm
	[PULR 320]	this figure indicates the number of PULses per Revolution. Normally this is equal to the number of teeth on the rack. Maximum number 400.
	[K1 S 2%]	this figure indicates the percentage deformation of the pipe (Stretching). Maximum permissible 20%.
	[K2 C 4%]	this figure indicates the percentage deformation of the pipe (Crushing). Maximum permissible 20%.
	[K3 F 0%]	this figure indicates the percentage difference between the First coil and the last. Maximum permissible 20%. (not active)
	[CALC?TAB]	CALCulating the TABLE.. Pressing ENTER gives you [CALTB*OK]
	[CALTB*OK]	It displays the calculation which has been done and the table filled in with the new parameters. Press the < cursor key to exit the automatic table calculator function.

[PRS ENAB] [PRS DIS]	Opportunity to disable input of pressure sensor in case of failure. (always enabled) Pressing > takes you to a sub-menu with the following options										
	<table border="1"> <tr> <td data-bbox="571 309 798 365">[DSRA PRS]</td> <td data-bbox="798 309 1516 365">=>it DiSables the Reading by the Assistance. (does not appear on assistance menu)</td> </tr> <tr> <td data-bbox="571 365 798 398">[ENRA PRS]</td> <td data-bbox="798 365 1516 398">=>ENables Read by the Assistance</td> </tr> <tr> <td data-bbox="571 398 798 432">[ENMA PRS]</td> <td data-bbox="798 398 1516 432">=>ENables Modification by the Assistance</td> </tr> <tr> <td data-bbox="571 432 798 465">[ENRU PRS]</td> <td data-bbox="798 432 1516 465">=>ENables Read-only by the User.</td> </tr> <tr> <td data-bbox="571 465 798 488">[DSRA PRS]</td> <td data-bbox="798 465 1516 488">=>ENables Modification by the User</td> </tr> </table>	[DSRA PRS]	=>it DiSables the Reading by the Assistance. (does not appear on assistance menu)	[ENRA PRS]	=>ENables Read by the Assistance	[ENMA PRS]	=>ENables Modification by the Assistance	[ENRU PRS]	=>ENables Read-only by the User.	[DSRA PRS]	=>ENables Modification by the User
[DSRA PRS]	=>it DiSables the Reading by the Assistance. (does not appear on assistance menu)										
[ENRA PRS]	=>ENables Read by the Assistance										
[ENMA PRS]	=>ENables Modification by the Assistance										
[ENRU PRS]	=>ENables Read-only by the User.										
[DSRA PRS]	=>ENables Modification by the User										
[END ENAB] [END DIS]	Opportunity to disable input of sensor of rewinding end in case of failure. (always enabled) Pressing > takes you to a sub-menu with the following options										
	<table border="1"> <tr> <td data-bbox="571 555 798 611">[DSRA PRS]</td> <td data-bbox="798 555 1516 611">=>it DiSables the Reading by the Assistance. (does not appear on assistance menu)</td> </tr> <tr> <td data-bbox="571 611 798 645">[ENRA PRS]</td> <td data-bbox="798 611 1516 645">=>ENables Read by the Assistance</td> </tr> <tr> <td data-bbox="571 645 798 678">[ENMA PRS]</td> <td data-bbox="798 645 1516 678">=>ENables Modification by the Assistance</td> </tr> <tr> <td data-bbox="571 678 798 712">[ENRU PRS]</td> <td data-bbox="798 678 1516 712">=>ENables Read-only by the User.</td> </tr> <tr> <td data-bbox="571 712 798 757">[DSRA PRS]</td> <td data-bbox="798 712 1516 757">=>ENables Modification by the User</td> </tr> </table>	[DSRA PRS]	=>it DiSables the Reading by the Assistance. (does not appear on assistance menu)	[ENRA PRS]	=>ENables Read by the Assistance	[ENMA PRS]	=>ENables Modification by the Assistance	[ENRU PRS]	=>ENables Read-only by the User.	[DSRA PRS]	=>ENables Modification by the User
[DSRA PRS]	=>it DiSables the Reading by the Assistance. (does not appear on assistance menu)										
[ENRA PRS]	=>ENables Read by the Assistance										
[ENMA PRS]	=>ENables Modification by the Assistance										
[ENRU PRS]	=>ENables Read-only by the User.										
[DSRA PRS]	=>ENables Modification by the User										
	<table border="1"> <tr> <td data-bbox="571 757 798 880">[WRE 0"]</td> <td data-bbox="798 757 1516 880">Wait Rewinding End: rewinding time in seconds after the impulse end sensor to complete the gun cart reloading process. Pressing > takes you to a sub-menu with the following options</td> </tr> </table>	[WRE 0"]	Wait Rewinding End: rewinding time in seconds after the impulse end sensor to complete the gun cart reloading process. Pressing > takes you to a sub-menu with the following options								
[WRE 0"]	Wait Rewinding End: rewinding time in seconds after the impulse end sensor to complete the gun cart reloading process. Pressing > takes you to a sub-menu with the following options										
	<table border="1"> <tr> <td data-bbox="571 880 798 936">[DSRA PRS]</td> <td data-bbox="798 880 1516 936">=>it DiSables the Reading by the Assistance. (does not appear on assistance menu)</td> </tr> <tr> <td data-bbox="571 936 798 969">[ENRA PRS]</td> <td data-bbox="798 936 1516 969">=>ENables Read by the Assistance</td> </tr> <tr> <td data-bbox="571 969 798 1003">[ENMA PRS]</td> <td data-bbox="798 969 1516 1003">=>ENables Modification by the Assistance</td> </tr> <tr> <td data-bbox="571 1003 798 1037">[ENRU PRS]</td> <td data-bbox="798 1003 1516 1037">=>ENables Read-only by the User.</td> </tr> <tr> <td data-bbox="571 1037 798 1115">[DSRA PRS]</td> <td data-bbox="798 1037 1516 1115">=>ENables Modification by the User .Pressing v takes you to a sub-menu with the following options</td> </tr> </table>	[DSRA PRS]	=>it DiSables the Reading by the Assistance. (does not appear on assistance menu)	[ENRA PRS]	=>ENables Read by the Assistance	[ENMA PRS]	=>ENables Modification by the Assistance	[ENRU PRS]	=>ENables Read-only by the User.	[DSRA PRS]	=>ENables Modification by the User .Pressing v takes you to a sub-menu with the following options
[DSRA PRS]	=>it DiSables the Reading by the Assistance. (does not appear on assistance menu)										
[ENRA PRS]	=>ENables Read by the Assistance										
[ENMA PRS]	=>ENables Modification by the Assistance										
[ENRU PRS]	=>ENables Read-only by the User.										
[DSRA PRS]	=>ENables Modification by the User .Pressing v takes you to a sub-menu with the following options										
	<table border="1"> <tr> <td data-bbox="571 1115 798 1173">[IER 3.0"]</td> <td data-bbox="798 1115 1516 1173">Elapsing time in seconds and tenths of seconds to increase the speed of the gun cart restart.</td> </tr> </table>	[IER 3.0"]	Elapsing time in seconds and tenths of seconds to increase the speed of the gun cart restart.								
[IER 3.0"]	Elapsing time in seconds and tenths of seconds to increase the speed of the gun cart restart.										

[UM METRE] o [UM FEET]	Units of measurement: decimal metric system. or, Imperial (US) measuring system. In this case the displays will relate to the irrigation parameters (length of pipe and speed). The rest of the data in the menus remains expressed in the decimal metric system.
------------------------	---

[LING ITA] o [LING FRA] o [LING ING] o [LING TED]	LANGUage used for displays. Activated after saving data.
---	--

[PWD ASST]	Setting a new Assistance password (to be implemented)
------------	---

[SYSTEM]	Parameters relating to configuration of the user interface. Pressing > takes you to a sub-menu with the following options:				
[MODE DIS]	Pressing > takes you to a sub-menu with the following options relating to some of the DISplays				
	<table border="1"> <tr> <td data-bbox="590 1680 782 1713">[DIS METR] o</td> <td data-bbox="782 1680 1516 1713">these options let you choose the displays of data for length and speed with or</td> </tr> <tr> <td data-bbox="590 1713 782 1747">[DIS DECM]</td> <td data-bbox="782 1713 1516 1747">without the decimal number.</td> </tr> </table>	[DIS METR] o	these options let you choose the displays of data for length and speed with or	[DIS DECM]	without the decimal number.
[DIS METR] o	these options let you choose the displays of data for length and speed with or				
[DIS DECM]	without the decimal number.				
	<table border="1"> <tr> <td data-bbox="590 1747 782 1780">[D RID RT] o</td> <td data-bbox="782 1747 1516 1780">these options let you choose various Displays during Rapid Test and manual</td> </tr> <tr> <td data-bbox="590 1780 782 1814">[D STD TR]</td> <td data-bbox="782 1780 1516 1814">control. The general default is RED</td> </tr> </table>	[D RID RT] o	these options let you choose various Displays during Rapid Test and manual	[D STD TR]	control. The general default is RED
[D RID RT] o	these options let you choose various Displays during Rapid Test and manual				
[D STD TR]	control. The general default is RED				
	<table border="1"> <tr> <td data-bbox="590 1814 782 1848">[D ALT MM] o</td> <td data-bbox="782 1814 1516 1848">these options let you choose various Displays during Movement of the</td> </tr> <tr> <td data-bbox="590 1848 782 1881">[D STD MM]</td> <td data-bbox="782 1848 1516 1881">Motors</td> </tr> </table>	[D ALT MM] o	these options let you choose various Displays during Movement of the	[D STD MM]	Motors
[D ALT MM] o	these options let you choose various Displays during Movement of the				
[D STD MM]	Motors				
[MODE KEY]	Pressing > takes you to a sub-menu with the following options relating to the functionalities of the keypad				

[I ALT SP] o [I STD SP]	these options let you choose how Increments in figures for length and SPeed will be made through the keypad during work. With [I STD SP] , Increments in the figures are as follows: the initial pause keys produce increments of hundreds; the SPeed keys produce Increments of tens; and the final pause keys produce increments of units. With [I ALT SP] , however, the Increments are in units only, using the SPeed keys.
--	---

[GSM OFF] [GSM ON]	Enables and disables the GSM function, if present
-------------------------------------	---

[SWOF 0']	Setting the minutes for auto-SWitchOff of the machine after the end of irrigation, for energy saving. Maximum programmable time = 99 minutes.
------------------	---

[CONTR 90]	Adjustment for CONTRast of the display: already described in the USER MENU.
-------------------	---

[BRIGH 80]	Adjustment for brightness of the display back-lighting: already described in the USER MENU
-------------------	--

Saving changes

Save changes in the Rain Star 260 memory as follows:

- see “saving changes” at the end of chapter 2

Once complete, the unit reboots and displays the message **[RE-START]** .

Cancelling changes

To cancel one or more changes, proceed as follows:

- see “cancelling changes” at the end of chapter 2

Once complete, the unit reboots and displays the message **[RE-START]** .